

# ELECTRIC-ASSISTED BICYCLES MAINTENANCE TABLE

ELECTRIC-ASSISTED BICYCLES MAINTENANCE INTERVALS AND PROCEDURES				MAINTENANCE MILEAGE (The interval between two maintenances must not exceed 6 (six) months)					
NO	PART/SYSTEM	GENERAL MAINTENANCE PROCEDURES	1.MONTH (BREAK-IN)	6.MONTH	12.MONTH	18.MONTH	24.MONTH	30.MONTH	36.MONTH
Check, Maintenance and Adjustment Operations									
1.a.	Front and Rear	Check that the brake cables are not jammed and operate properly; adjust if necessary.	●	●	●	●	●	●	●
1.b.	Front and Rear	Check the brake discs and replace them if necessary.	●	●	●	●	●	●	●
2	Motor Unit	It should be checked at every maintenance.	●	●	●	●	●	●	●
3	Battery	Measure the battery voltage; fully charge or replace if necessary. Check the tightness of the terminal connections.	●	●	●	●	●	●	●
4	Chain Inspection	The chain should be inspected, and the ideal tension checked. It must be lubricated every two maintenances.	●	●	●	●	●	●	●
5	Bicycle Frame	The bicycle frame should be inspected.	●	●	●	●	●	●	●
6	Foot Pedal	The condition of the pedals should be checked.	●	●	●	●	●	●	●
7	Fastening Elements	Make sure all nuts and bolts are properly tightened.	●	●	●	●	●	●	●
8	Lighting Components	Check the operation of the front and rear lights and switches.	●	●	●	●	●	●	●
9	Gear System	Check the gear shifting.	●	●	●	●	●	●	●
10	Wheel Bearings	Check that there is no play in the hub and that the wheels spin freely.	●	●	●	●	●	●	●
11	Tyres	Check the tire air pressures, inspect for any damage, and verify the tread depth.	●	●	●	●	●	●	●
12	Rims	Check for any leakage or damage.	●	●	●	●	●	●	●

**NOTE:** The first maintenance of your electric bicycle must be performed in the 1st month. The initial service is for inspection purposes. The next maintenance should be done when the 6th month is reached. After this, every maintenance should occur at intervals of 6 months or multiples thereof. The time between any two maintenances must not exceed 6 months. Vehicles that do not comply with the periodic maintenance intervals will be excluded from the warranty coverage.



**VOLTA MOTOR SAN. TİC. AŞ**  
 Merkez Mah. Yıldıztepe Cad. Gümüşova OSB Gümüşova / DÜZCE  
 0380 731 25 25 - 0380 731 25 35 - info@volta.com.tr